




HORIZONTÁLNÍ ZÁSOBNÍK




Návod na stavění – sety LEGO® Education 45544 a 45560





1






2



3



4





9






15 1:1

5



















6







8


- 4x 
- 1x 
- 9x 
- 2x 
- 1x 
- 4x 
- 2x 
- 2x 
- 9x 
- 1x 
- 1x 




2x





9



10






11






15 1:1

12



13



5





9







15 1:1


14



15



16



18

